

TREWGrip™ Mobile Dock

Thank you for purchasing the TREWGrip™ Mobile Dock. This *Quick Start Guide* gives you an overview of the features and functionality, and provides details on how to operate your new TREWGrip unit.

What's Included

- TREWGrip Mobile Dock with Small, Medium or Large Grips
- Small Docking Plate (for smartphone)
- Large Docking Plate (for phablet or mini-tablet)
- USB Wall Adapter (US)
- USB Charging Cable
- Quick Start Guide



Charging

1. Connect the USB Charging Cable to the USB Wall Adapter
2. Plug the USB Wall Adapter into a standard wall outlet
3. Connect the USB Charging Cable to the Micro USB port on the top of TREWGrip

Please note: TREWGrip needs approximately 4-hours to fully charge

Power On/Off

- Power On: press the **left** or **right mouse button**
- Power Off: press the **Func** key, and then press the **S** key



Please note: TREWGrip will automatically power off after 10-minutes of inactivity

Pairing

TREWGrip connects via Bluetooth (2.0 or higher) to a variety of computers/devices using the HID (Human Interface Device) Specification. For pairing instructions, please refer to the operating manual for your computer/device. If a security code is required during the pairing process, enter "1234".

TREWGrip is automatically discoverable on pairing channel 1, as indicated by the *slow* flashing green light when you power on TREWGrip for the first time. Once paired, the pairing indicator for channel 1 will switch to solid green.

To change pairing channels (1, 2 or 3):

1. Press the **Func** key
2. Press the **up arrow** or **down arrow** button



If a device is already paired on a channel, the pairing indicator will flash *fast*. To reconnect to a previously paired device, press the **left mouse** button.

To disconnect a pairing:

1. Press the **Func** key
2. Press the **D** key (once pressed, the pairing indicator will flash *fast*)

To delete a pairing:

1. Press the **Func** key
2. Press the **Del** button (once pressed, the pairing indicator will flash *slow*)





Operating Modes

Your TREWGrip mobile dock has *Keyboard/Mouse* and *Keyboard/Game Controller* operating modes.

To toggle operating modes:

1. Press the **Func** key
2. Press the **Tab** key

Please note: when you toggle to Keyboard/Mouse mode the K and M indicators will illuminate, and Keyboard/Game Controller mode the K and G indicators.

Air Mouse

TREWGrip uses an accelerometer and gyroscope to control mouse movement, and can be configured for absolute movement (default) and relative movement (required for Android devices and multiple monitors).

To toggle absolute/relative movement:

1. Press the **Func** key
2. Press the **Backspace** key

When configured for absolute movement, the mouse pointer will need to be centered (or calibrated) to a neutral position while holding TREWGrip. Please note that the neutral position will change based on how you are using TREWGrip (standing/sitting).

To center the mouse pointer for absolute movement:

1. Press the **Func** key
2. Hold TREWGrip in a neutral position (comfortable position)
3. Press the **Enter** key

Docking Plates

Small and large docking plates, with adhesive backing, are included for docking a smartphone, phablet or mini-tablet onto TREWGrip. Adhere the small docking plate to your smartphone, and large docking plate to your phablet or mini-tablet.



Important: after adhering a docking plate to your smartphone, phablet or tablet, please wait 24-hours before docking your device onto TREWGrip. This will give the adhesive sufficient time to cure. If your device is in a case, please note that the case will affect how securely your device is docked onto TREWGrip. We strongly recommend that you test how secure your device is docked, using a soft surface like a pillow, before routine use. If you have any questions, please contact TREWGrip Support.

Learning TREWGrip

Please visit www.trewtypist.com for instructions and exercises that will help you transition your touch typing skills to TREWGrip. Although results will vary, most touch-typists can learn TREWGrip within 1-hour.

Support

For additional instructions and support, please visit www.trewgrip.com. If you require technical support, please e-mail support@trewgrip.com or call 1-800-984-9346. Support hours are Monday – Friday from 9AM to 6PM EST.